BO200R

Reference: BO200R0-...

Included:

| 4x Concrete screw (ø17x130mm) | 4x Flanged spacer Ø19xØ27xØ32mm |

Required Tools

Electric drill | Ø 14 mm | Impact Wrench >500 Nm + Extension part + Socket SW21 | Dust remover (Air)

---

1 Position and mark location of all 4 holes

(Front side)

---

2 Move product to side and drill all holes (Ø14 x 120mm)

120
Ø14

---

3 Remove debris from holes

---

4 Insert the flanged spacers flush into the holes of the flexible base

---

5 Insert screws

---

6 Tighten screws with wrench; Torque = 100 Nm

Done!

---

boplan® READY FOR IMPACT

For more information, please visit **www.boplan.com**

Rev: 26 February 2024 10:57 am